

Version: V1.00.000
Revised date: 04-05-2017

Copyright Information

Copyright © 2017 by LAUNCH TECH. CO., LTD. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of LAUNCH. The information contained herein is designed only for the use of this unit. LAUNCH is not responsible for any use of this information as applied to other units.

Neither LAUNCH nor its affiliates shall be liable to the purchaser of this unit or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this unit, or unauthorized modifications, repairs, or alterations to this unit, or failure to strictly comply with LAUNCH operating and maintenance instructions. LAUNCH shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original LAUNCH Products or LAUNCH Approved Products by LAUNCH.

Trademark Information

LAUNCH is a registered trademark of LAUNCH TECH CO., LTD. (also called LAUNCH for short) in China and other countries. All other LAUNCH trademarks, service marks, domain names, logos, and company names referred to in this manual are either trademarks, registered trademarks, service marks, domain names, logos, company names of or are otherwise the property of LAUNCH or its affiliates. In countries where any of the LAUNCH trademarks, service marks, domain names, logos and company names are not registered, LAUNCH claims other rights associated with unregistered trademarks, service marks, domain names, logos, and company names. Other products or company names referred to in this manual may be trademarks of their respective owners. You may not use any trademark, service mark, domain name, logo, or company name of LAUNCH or any third party without permission from the owner of the applicable trademark, service mark, domain name, logo, or company name. You may contact LAUNCH by visiting the website at www.cnlaunch.com, or writing to LAUNCH TECH. CO., LTD., Launch Industrial Park, North of Wuhe Avenue, Banxuegang, Bantian, Longgang, Shenzhen, Guangdong, P.R.China, to request written permission to use Materials on this manual for purposes or for all other questions relating to this manual.

Important Safety Precautions

Important: To avoid personal injury, property damage, or accidental damage to the product, read all of the information in this section before using the product.

- Never collide, throw, or puncture CRP MOT, and avoid falling, extruding and bending it.
- Do not insert foreign objects into or place heavy objects on your device. Sensitive components inside might cause damage.
- Do not use CRP MOT in exceptionally cold or hot, dusty, damp or dry environments.
- In places using CRP MOT may cause interference or generate a potential risk, please turn it off.
- CRP MOT is a sealed unit. There are no end-user serviceable parts inside. All internal repairs must be done by an authorized repair facility or qualified technician. If there is any inquiry, please contact the dealer.
- Never place CRP MOT into apparatus with strong electromagnetic field.
- Keep CRP MOT far away from magnetic devices because its radiations can damage the screen and erase the data stored on CRP MOT.
- DANGER: Do not attempt to replace the internal rechargeable lithium battery. Contact the dealer for factory replacement.
- CAUTION: Please use the included battery and charger. Risk of explosion if the battery is replaced with an incorrect type.
- Do not disconnect power abruptly when CRP MOT is being formatted or in process of uploading or downloading. Or else it may result in program error.
- Do not delete unknown files or change the name of files or directories that were not created by you, otherwise your CRP MOT software might fail to work.
- Be aware that accessing network resources can leave your CRP MOT vulnerable to computer viruses, hackers, spyware, and other malicious activities that might damage your device, software or data. It is your responsibility to ensure that you have adequate protection in the forms of firewalls, antivirus software, and anti-spyware software and keep such software up to date.

Precautions on Using CRP MOT

Before using this test equipment, please read the following safety information carefully.

- Always perform automotive testing in a safe environment.
- If the VCI connector remains unused for a long period of time, it is suggested to unplug the connector from vehicle's DLC to conserve battery power.

- Wear an ANSI-approved eye shield when testing or repairing vehicles.
- The vehicle shall be tested in a well ventilated work area, as engines produce various poisonous compounds (hydrocarbon, carbon monoxide, nitrogen oxides, etc.)
- Do not connect or disconnect any test equipment while the ignition is on or the engine is running.
- Put blocks in front of the drive wheels and never leave the vehicle unattended while testing.
- Keep the test equipment dry, clean, free from oil, water or grease. Use a mild detergent on a clean cloth to clear the outside of the equipment as necessary.
- Do not drive the vehicle and operate the test equipment at the same time. Any distraction may cause an accident.
- Keep clothing, hair, hands, tools, test equipment, etc. away from all moving or hot engine parts.
- Before starting the engine, put the gear lever in the Neutral position (for manual transmission) or in the Park (for automatic transmission) position to avoid injury.
- To avoid damaging the test equipment or generating false data, please make sure the vehicle battery is fully charged and the connection to the vehicle DLC (Data Link Connector) is clear and secure.
- Automotive batteries contain sulfuric acid that is harmful to skin. In operation, direct contact with the automotive batteries should be avoided. Keep the ignition sources away from the battery at all times.

Precautions on Operating Vehicle's ECU

- Do not disconnect battery or any wiring cables in the vehicle when the ignition switch is on, as this could avoid damage to the sensors or the ECU.
- Do not place any magnetic objects near the ECU. Disconnect the power supply to the ECU before performing any welding operations on the vehicle.
- Use extreme caution when performing any operations near the ECU or sensors. Ground yourself when you disassemble PROM, otherwise ECU and sensors can be damaged by static electricity.
- When reconnecting the ECU harness connector, be sure it is attached firmly, otherwise electronic elements, such as ICs inside the ECU, can be damaged.

TABLE OF CONTENTS

1 INTRODUCTIONS	1
1.1 PRODUCT PROFILE	1
1.2 FEATURES	1
1.3 KNOWLEDGE OF CRP MOT	2
1.3.1 CRP MOT whole set.....	2
1.3.2 CRP MOT handset.....	2
1.3.3 VCI connector (Only applies to 12V passenger vehicles).....	3
1.4 TECHNICAL PARAMETERS.....	4
1.5 PACKAGE LIST	5
2 PREPARATIONS	6
2.1 CHARGING CRP MOT	6
2.2 USING YOUR BATTERY	6
2.3 POWER ON/OFF	6
2.3.1 Power on.....	6
2.3.2 Power off.....	6
2.4 TIPS ON FINGER OPERATIONS	6
2.5 LOCK & UNLOCK THE SCREEN	7
2.5.1 Lock the screen.....	7
2.5.2 Unlock the screen	7
2.6 SCREEN LAYOUT	8
2.7 NOTIFICATION PANEL	8
2.8 CUSTOMIZE YOUR DESKTOP.....	8
2.8.1 Create a widget on the desktop.....	8
2.8.2 Move items on the desktop	8
2.8.3 Delete items from the desktop.....	8
2.8.4 Adjust brightness.....	8
2.8.5 Set standby time	9
2.9 SET SCREEN LOCK	9
3 WI-FI SETTING	10
3.1 CONNECT TO A WI-FI NETWORK	10
3.2 DISCONNECT FROM A WI-FI NETWORK.....	10
4 INITIAL USE & VEHICLE CONNECTION	11
4.1 DIAGNOSIS FLOWCHART	11
4.2 INITIAL USE	11
4.2.1 User registration.....	11

4.2.2 Function menu	14
4.3 CONNECTIONS	14
4.3.1 Preparation.....	14
4.3.2 DLC location	14
4.3.3 Vehicle connection	15
4.4 BLUETOOTH SETTING	16
5 START DIAGNOSTICS	17
5.1 HEALTH REPORT (QUICK TEST)	17
5.1.1 View fault report	18
5.1.2 Clear DTC	19
5.2 SYSTEM SCAN	19
5.3 SYSTEM SELECTION	20
5.3.1 Version Information	21
5.3.2 Read Fault Code	21
5.3.3 Clear Fault Memory.....	22
5.3.4 Read Data Stream.....	22
6 RESET	26
7 golo	29
7.1 INTERFACE LAYOUT	29
7.2 ADD FRIENDS.....	29
7.3 START INSTANT MESSAGING	30
7.4 LAUNCH REMOTE DIAGNOSIS	31
8 SOFTWARE UPDATE	34
9 PROFILE	35
9.1 MY CONNECTOR.....	35
9.2 ACTIVATE CONNECTOR	35
9.3 FIRMWARE FIX	35
9.4 MY REPORT	36
9.5 DIAGNOSTIC FEEDBACK	36
9.6 PROFILE	36
9.7 CHANGE PASSWORD	36
9.8 LOG OUT.....	37
10 SETTINGS.....	38
10.1 UNITS OF MEASUREMENT	38
10.2 PRINT INFORMATION.....	38
10.3 DIAGNOSTIC FEEDBACK.....	38

10.4 ABOUT	38
11 OTHERS	39
11.1 EMAIL	39
11.1.1 Configure an email account	39
11.1.2 Add an email account	39
11.2 BROWSER.....	39
11.2.1 Open browser	39
11.2.2 Download files	40
11.3 SYNCHRONIZATION.....	40
11.3.1 Connect to PC	40
11.3.2 Run on PC.....	40
11.3.3 Install an application	40
11.4 CLEAR CACHE.....	41
12 FAQ	42

1 Introductions

1.1 Product Profile

CRP MOT is a stylish Android-based vehicle trouble diagnostic tool. It inherits from LAUNCH's advanced diagnosing technology and is characterized by covering a wide range of vehicles, featuring powerful functions, and providing precise test result.

Through the simple Bluetooth communication between the VCI connector and CRP MOT, it achieves full car model and full system vehicle trouble diagnosis, which includes Reading DTCs, Clearing DTCs and Reading Data Stream.

Moreover, it supports Wi-Fi connection, which enables you surf the Internet, update the diagnostic software online and perform remote diagnosis etc, getting your job fixed faster and easier.

1.2 Features

1. Diagnostics:

A. Diagnose

- ♦ Diagnose the electronic control systems of prevailing vehicle models covering Asian, European, American and Chinese. Diagnosis functions include: Read DTCs, Clear DTCs, Read data stream, Special functions etc.
- ♦ Specially designed for Android platform with clear and user-friendly interface.
- ♦ Via Bluetooth, it is simple for the VCI connector to communicate with CRP MOT.

B. Reset: Includes all kinds of maintenance resets.

C. One-click Update: lets you update diagnostic software and APK more efficiently.

D. golo: configures CRP MOT as I/M (Instant Messaging) tool, which enables technicians to exchange repair experience and perform remote assistance more conveniently.

2. Browser: built-in Wi-Fi module makes surfing on the internet freely.
3. Email: allows you to send and receive emails.
4. Settings: to configure your personalized CRP MOT through it.
5. Applications: other android based applications can be customized to install or uninstall.

1.3 Knowledge of CRP MOT

1.3.1 CRP MOT whole set

CRP MOT is mainly composed of a CRP MOT handset, and a VCI connector.

1.3.2 CRP MOT handset




Fig. 1-1 CRP MOT tablet

- | | | |
|---|--------------------------|--|
| 1 | USB/Charging port | To connect to the power adaptor for charging the CRP MOT tablet. |
| 2 | Speakers | |
| 3 | LCD screen | |
| 4 | Rear camera | |

5	POWER/Screen lock key	In Off mode, press it to turn CRP MOT on; In On mode, turn CRP MOT off with long press or lock screen with short press.
6	VOLUME +/- Key	To adjust the volume. To print the screen, hold and press the POWER and VOLUME – key until a snapshot pops up on the screen. The captured snapshot is saved in the "Screenshots" folder.
7	VCI connector	
8	Slot for VCI connector	For housing the VCI connector.

1.3.3 VCI connector (Only applies to 12V passenger vehicles)




Fig. 1-2 VCI connector

1	OBD-16 diagnostic connector	To connect on vehicle's OBD2 DLC.
---	------------------------------------	-----------------------------------

2	Mini USB port	For connecting the USB cable to the tablet to perform vehicle diagnosis. (Note: This port is disabled for CRP MOT.)
3	Mode indicator	<ul style="list-style-type: none"> • It illuminates red when the VCI connector is connected to the vehicle's DLC. • Blue indicates the VCI connector is working in Bluetooth mode.

1.4 Technical Parameters

CRP MOT:

Operating system	Android 6.0
Processor	Quad core 1.0 GHz
Memory	1GB
Storage	16GB (Expandable up to 32GB)
LCD screen	7 inch IPS screen with a resolution of 1024 x 600 pixels
Camera	Front-facing 2MP camera + rear-facing 5MP camera
Battery	3450mh rechargeable polymer lithium battery
Connectivity	<ul style="list-style-type: none"> ♦ Wi-Fi: WLAN 802.11b/g/n ♦ Bluetooth: Bluetooth 4.1
Working temperature	0°C ~ 45°C
Storage temperature	-10°C ~ 50°C

VCI connector:

Working voltage	9 ~18V
Working temperature	-10°C ~ 55°C
Storage temperature	-20°C ~ 70°C
Relative humidity	20% ~ 90%

1.5 Package List



While opening CRP MOT package for the first time, please carefully check the following components. Common accessories for each CRP MOT are same, but for different destinations, the accessories of CRP MOT may vary. Please consult from the local agency or check the package list supplied with CRP MOT together.

- CRP MOT tablet
- Password envelope (A piece of paper bearing Product S/N and Activation Code for product registration)
- VCI connector (For connecting OBD II vehicles)
- OBD II extension cable (For connecting the VCI connector to OBD II vehicle)
- OBD I adaptor (For connecting the non-16pin diagnostic connector and the VCI connector)
- Power adaptor (For charging the CRP MOT tablet)
- Non-16pin connectors (For connecting non-OBD II vehicle)

2 Preparations

2.1 Charging CRP MOT

1. Plug one end of the included power adaptor into the USB port of the CRP MOT.
2. Connect the other end to the AC outlet.

If  appears on the screen, it indicates it is being charged. If the logo changes into , it indicates that the battery is fully charged. Unplug the power adaptor from CRP MOT.


2.2 Using your battery

- If the battery remains unused for a long period of time or the battery is completely discharged, it is normal that the tool will not power on while being charged. Please charge it for a period of 5 minutes and then turn it on.
- Please use the included power adaptor to charge your tool. No responsibility can be assumed for any damage or loss caused as a result of using power adaptors other than the one supplied.
- While CRP MOT has low battery, a beep will sound. If it is very low, CRP MOT will be switched off automatically.

2.3 Power on/off

2.3.1 Power on

Press [POWER] to turn the tool on.

 Note: If it is the first time you have used this tool or the tool remains idle for a long period of time, the tool could fail to turn on. Please charge the tool for a minimum of 5 minutes and attempt to turn on again.

2.3.2 Power off

Press [POWER] for 3 seconds, an option menu will pop up on the screen. Tap "Power off" to turn the tool off.

2.4 Tips on finger operations



Single-tap: To select an item or launch a program.



Double-tap: To zoom in so that the text on a webpage appears in a column that fits your device's screen.



Long press: Tap and hold on the current interface or area until a contextual menu pops up on the screen, and then release it.



Slide: To jump to different pages.




Drag: Tap the application icon and drop it to other location.



Spread apart/pinch together: To zoom in manually, place two fingers on the screen and then spread them apart. To zoom out, place two fingers apart on the screen and then pinch them together.

2.5 Lock & unlock the screen

Many screen lock modes are available on CRP MOT.


 Note: You are recommended to set screen lock as “None” since CRP MOT is a frequently used diagnostic tool.

2.5.1 Lock the screen

- When it is ON, press [POWER] once to lock the screen;
- The system will lock the screen automatically after CRP MOT remains idle over the preset standby time.





2.5.2 Unlock the screen

Press [POWER] to activate the screen and drag the lock to “Unlock” position.

 Note: If you define as unlock using the pattern, you have to draw the right target pattern to unlock it.

2.6 Screen layout

There are four on-screen buttons available on the bottom of the screen.

BACK	Tap  to return to the previous screen.
HOME	Tap  to navigate to the Android's home screen.
Recent Apps	Tap  to view the recently launched applications.
Screenshot	Tap  to capture the current screen.

2.7 Notification panel

The notification bar is used to display some activities, such as new message, to do list and running tasks. You can also open the notification bar to view the reminder or activity notification.

2.8 Customize your desktop


2.8.1 Create a widget on the desktop

Tap and hold the desired application or widget, and then drag it to the target position.


2.8.2 Move items on the desktop

Tap and hold the item to be moved, and drag and drop it to the target location.


2.8.3 Delete items from the desktop

 **Warning:** Deleting an icon will uninstall the corresponding application. Please be careful to do so.

1. Tap and hold the item to be moved until it is shaken.
2. Drag it on the trash icon and release it.

 **Note:** If no trash icon appears on the top of the screen, it indicates that the application cannot be uninstalled.

2.8.4 Adjust brightness

 **Tips:** Reducing the brightness of the screen is helpful to save the power of CRP MOT.

1. On the home screen, tap Settings > Display > Brightness level.
2. Drag the slider to adjust it.

2.8.5 Set standby time


If no activities are made within the defined standby period, the screen will be locked automatically and the system enters sleep mode to save power.

1. On the home screen, tap Settings > Display > Sleep.
2. Choose the desired sleep time.


2.9 Set screen lock

This function is designed to lock the screen and buttons to avoid accidental operations while CRP MOT keeps unused.

1. On the home screen, tap Settings > Security > Screen lock.
2. Choose the desired screen lock mode and follow the on-screen instructions to finish your setting.

 Note: You are recommended to set screen lock as “None” since CRP MOT is a frequently used diagnostic tool.


3 Wi-Fi Setting

 Note: If you don't need to use Wi-Fi for a while, you can turn it off to conserve battery life.

CRP MOT has built-in Wi-Fi that can be used to get online. Once you're online, you can register your CRP MOT, surf the Internet, get apps, send email, launch the remote diagnosis, and check for software updates etc.

3.1 Connect to a Wi-Fi network

1. On the home screen, tap **Settings -> WLAN**.
2. Slide the Wi-Fi switch to ON, CRP MOT will start searching for available wireless networks.
3. Select a wireless network,
 - If the chosen network is open, CRP MOT will connect automatically;
 - If the selected network is encrypted, a network password will need to be entered.
4. When "Connected" appears, it indicates the Wi-Fi connection is complete.

 Note: When Wi-Fi is not required, this should be disabled to conserve battery power.

Once it is connected successfully, tap the Wi-Fi network from the list to view its name, link speed, security type, IP address etc.

When this tool is in range, it will connect to the previously linked network automatically.

3.2 Disconnect from a Wi-Fi network

1. On the home screen, tap **Settings -> WLAN**.
2. Tap the network with a **Connected** status, then tap "Disconnect".

4 Initial Use & Vehicle Connection

4.1 Diagnosis Flowchart

For new users, please follow the operation chart shown in Fig. 4-1 to get familiar with and start using CRP MOT.




Fig. 4-1


4.2 Initial Use

During initial use, tap the CRP MOT application icon on the home screen to launch it and enter the main menu screen.

By default, all software is pre-installed on the CRP MOT and can be used to diagnose vehicles even if you do not experience the product registration. To enable you to get one-click update and enjoy more functions and better service, you are recommended to make app sign-up and product activation for the first time.

4.2.1 User registration


Tap "Login" on the upper right corner of the main menu screen:



The image shows a login screen with a red header containing the word "Login". Below the header are two input fields: "Username" with a person icon and a dropdown arrow, and "Password" with a lock icon and an eye icon. A red "Login" button is positioned below these fields. At the bottom of the screen, there are two links: "Retrieve password" on the left and "New Registration" on the right.


Fig. 4-2

1. If you are a new user, tap "New Registration". See Fig. 4-3.



The image shows a "Create an Account" screen with a progress bar at the top indicating three steps: "Create an Account" (active), "Activate Connector", and "Finish Registration". The form is divided into two columns. The left column contains four input fields: "Username", "Password", "Confirm Password", and "Email". The right column contains a "Select Country" dropdown, a "CAPTCHA" input field with the value "5169" and a red "CAPTCHA" button, and a large grey "Register" button at the bottom.

Fig. 4-3

 Note: To obtain better service, you need to provide real information.

- A. Create App account: In Fig. 4-3, fill in the information in each field and then tap "Register", a screen similar to the following will appear:



The image shows an "Activate Connector" screen with a progress bar at the top indicating three steps: "Create an Account", "Activate Connector" (active), and "Finish Registration". The form has three input fields: "Serial Number", "Activation Code", and a larger field labeled "Where is my activation code?". A large grey "Activate" button is at the bottom.

Fig. 4-4

- B. Activate the VCI connector: In Fig. 4-4, input the Serial Number and Activation Code, which can be found in the password envelope.




Fig. 4-5

Note: To exit and activate it later, tap “Skip”. In this case, you can activate your connector by tapping “Activate Connector” in “Personal Center”. For details, please refer to Chapter 4.9.3 Activate Connector.

C. Download diagnostic software: Tap “Activate”, a dialog box similar to Fig. 4-6 will appear:




Fig. 4-6

To download the diagnostic software, tap “Yes” to enter the software download page. Tap “No” to download it later.

On the download page, tap “Update” to start downloading. It may take several minutes to finish it, please be patient to wait. To pause downloading, tap “Pause”. To resume it, tap “Continue”.

Once download is complete, the system will install the software package automatically.

2. If you have registered to be a member, input your name and password, and then tap the “Login” button to enter the main menu screen directly.

Note: CRP MOT has an auto-save function. Once the username and password are correctly entered, the system will automatically store it. Next time you login the system, you will not be asked to input the account manually.

3. If you forgot the password, tap “Retrieve Password”, and then follow the on-screen instructions to retrieve it.

4.2.2 Function menu

It mainly includes the following items:

Name	Description
Diagnostic	Configures CRP MOT to operate as a diagnostic tool.
Reset	To perform some maintenance items, including electronic throttle position reset, ABS bleeding, oil lamp reset etc.
golo	This option aims to help repair shops or technicians to get the repair job fixed faster.
Update	To update vehicle diagnostic software.
Profile	To manage, activate your VCI connector, diagnostic report or personal information etc.
Settings	Allows you to configure system settings, wireless printer and feedback the diagnostic reports/bugs to us for analysis.

4.3 Connections

4.3.1 Preparation

Normal testing conditions

- Turn on the vehicle power supply.
- Vehicle battery voltage range should be 9-14 Volts.
- Throttle should be in a closed position.

Select the VCI connector

If CRP MOT is testing vehicles equipped with universal OBD II diagnostic socket, please use the included VCI connector. (For vehicles with non-OBD II diagnostic socket, a non-16 pin connector is required.)

4.3.2 DLC location

The DLC (Data Link Connector) is typically a standard 16-pin connector where diagnostic tools interface with a vehicle's on-board control modules. The DLC is usually located 12 inches from the center of the instrument panel, under or around the driver's side for most vehicles. If DLC is not located under dashboard, a label should be there telling location. For some Asian and European vehicles, the DLC is located behind the ashtray and the ashtray must be removed to access the connector. If the DLC cannot be found, refer to the vehicle's service

manual.




Fig. 4-7

4.3.3 Vehicle connection

The method used to connect the VCI connector to a vehicle's DLC depends on the vehicle's configuration as follows:

- A vehicle equipped with an OBD II management system supplies both communication and 12V power through a standardized DLC.
- A vehicle not equipped with an OBD II management system supplies communication through a DLC connection, and in some cases supplies 12V power through the cigarette lighter receptacle or a connection to the vehicle battery.

Follow the steps mentioned below to connect OBD II vehicle:

1. Locate vehicle's DLC socket.
2. Plug the VCI connector into the vehicle's DLC socket (It is suggested to use the OBD II extension cable to connect the VCI connector and DLC socket).
3. Choose one of the two ways to obtain power from:
 - A. Power adaptor: Connect one end of the included power adaptor to DC IN port of CRP MOT tablet, and the other end to AC outlet.
 - B. Internal battery pack

For non-OBDII vehicle, proceed as follows:

1. Locate vehicle's DLC socket.
2. Select the corresponding non-16pin connector.
3. Plug the non-16pin end of the connector into the DLC socket, then connect the other end to the OBD I adaptor, and then tighten the captive screws.
4. Connect the other end of the adaptor to the included VCI connector.
5. To supply power to OBD I adaptor from:


A. Cigarette Lighter cable(optional): Connect one end of the cigarette lighter cable to vehicle's cigarette lighter receptacle, and the other end to the power jack of OBD I adaptor.

B. Battery Clamps Cable(optional): Connect one end of the battery clamps cable to vehicle's battery, and the other end to the power jack of OBD I adaptor.

4.4 Bluetooth Setting

Enter CRP MOT Bluetooth setting screen ("Settings" -> "Bluetooth"), slide the Bluetooth switch to ON and CRP MOT will start searching available Bluetooth device, tap the desired connector to pair.

By default, the Bluetooth name is 98639*****00 (where ***** stands for 5 digits.).

 Note: In case no Bluetooth setting is done before diagnostic software is launched, you can also configure it while using the software. For details on Bluetooth connection, please refer to Chapter 5 "Start diagnostics".

5 Start Diagnostics

Follow the steps mentioned below to start a new diagnostic session. Tap “Diagnostic”, and then tap a corresponding diagnostic software logo. Take Demo as an example to demonstrate how to diagnose a vehicle.

1). Tap the “DEMO”, a screen similar to the following appears:




Fig. 5-1

2). Tap “Demo” to ignore Bluetooth connection and jump to the test item selection screen. (Note: No Bluetooth connection is required for DEMO program.)



Fig. 5-2

5.1 Health Report (Quick Test)

This function varies from vehicle to vehicle. It enables you to quickly access all the electronic control units of the vehicle and generate a detailed report about vehicle health.

Tap “Health Report”, the system start scanning the ECUs. Once the scanning is complete, a screen similar to the following appears:




Fig. 5-3

In Fig. 5-3, the tested system with fault code appears in red and the system with OK displays in black (normally).

Tap the desired system to enter the test function selection page. For detailed operations on test function, please refer to Chapter 5.3.

On-screen Buttons:

Clear DTC: Tap to clear the existing diagnostic trouble codes. See Chapter 5.1.2.

Fault Report: Tap to view the health report in details. See Chapter 5.1.1.

5.1.1 View fault report

This function allows you to view the health report in details.




Fig. 5-4

In Fig. 5-4,

1 indicates the tested system with fault codes. Tap certain system to view the detailed definitions of the DTCs. See Fig. 5-5.

2 stands for the total number of the tested systems.

3 indicates the total number of the fault codes existing in the tested system.

Diagnostic Trouble Code		Login
DEMO > Health Report		
System	Content	State
Fault (8)		
ECM(Engine Control Module)	(4)	Abnormal
P0303 Misfiring of Cylinder 3(P0303)		
Normal (1)		
BMS(Battery Manager System)		Normal
Help	Search	Report

Fig. 5-5

On-screen Buttons:

Search: Highlight a certain DTC item, and then tap it to launch the browser to search for more detailed information about the selected DTC online.

Report: To save the current data in text format. All reports are saved under the tab "Diagnostic Report" in "My Report" from "Profile" menu. For details on report operations, please refer to Chapter 9.4 "My Report".


5.1.2 Clear DTC

This function lets you clear the existing diagnostic trouble codes in health report. Tap "Clear DTC", a confirmation dialog box appears. Tap "Yes" to clear all the diagnostic trouble codes. Tap "No" to abort it.

5.2 System Scan

This option allows you to quickly scan which systems are installed on the vehicle.

In Fig. 5-2, tap "System Scan", the system start scanning the systems. Once the scanning is complete, the screen will display the result. See Fig. 5-6.



Select Test Item		Login
DEMO > System Scan		
System Name	Result	
ECM(Engine Control Module)	Equipped	
TCM(Transmission Control Module)	Equipped	
ABS(Anti-lock Braking System)	Equipped	
SRS(Supplemental Inflatable Restraint System)	Equipped	
BCM(Body Control Module)	Equipped	

Fig. 5-6

In Fig. 5-3, tap the desired system to advance to the test function selection page. For detailed operations on test function, please refer to Chapter 5.3.

5.3 System Selection

This option allows you manually select the test system and function step by step. In Fig. 5-2, tap “System Selection”, the screen displays as follows:



Show Menu	Login
DEMO > System Selection	
ECM(Engine Control Module)	
TCM(Transmission Control Module)	
ABS(Anti-lock Braking System)	
SRS(Supplemental Inflatable Restraint System)	
BCM(Body Control Module)	

Fig. 5-7

Swipe the screen from the bottom to view the vehicle system on the next page. Tap the desired system (take “ECM” for example) to jump to the test function page.




Fig. 5-8

Note: Different vehicle has different diagnostic menus.

5.3.1 Version Information

This function is used to read the version information of system mode, vehicle VIN, software and ECU.

In Fig. 5-8, tap “Version Information”, the screen displays as Fig. 5-9.




Fig. 5-9

Tap “OK” to confirm and exit.

5.3.2 Read Fault Code

This function displays the detailed information of DTC records retrieved from the vehicle's control system.

In Fig. 5-8, tap “Read DTC”, the screen will display the diagnostic result.

Diagnostic Trouble Code			Login
DEMO > System Selection > ECM(Engine Control Module)			
DTC	Description	State	
P0303	Misfiring of Cylinder 3(P0303)		
P2097	Throttle Valve Block(Ice up)		
P0401	EGR Valve A Flow Insufficient Detected		
P0174	System A/F Ratio too Lean (Bank 2)		
<input type="button" value="Help"/> <input type="button" value="Search"/> <input type="button" value="Report"/> <input type="button" value="Freeze Frame"/>			

Fig. 5-10

On-screen Buttons:

Search: Highlight a certain DTC item, and then tap it to search for more information about the selected DTC online.

Report: To save the current data in text format. All reports are saved under the tab "Diagnostic Report" in "My Report" from "Profile" menu. For details on report operations, please refer to Chapter 9.4 "My Report".

Freeze Frame: When an emission-related fault occurs, certain vehicle conditions are recorded by the on-board computer. This information is referred to as freeze frame data. Freeze frame data includes a snapshot of critical parameter values at the time the DTC is set.

5.3.3 Clear Fault Memory

After reading the retrieved codes from the vehicle and certain repairs have been carried out, you can use this function to erase the codes from the vehicle. Before performing this function, please be sure the vehicle's ignition key is in the ON position with the engine off.

In Fig. 5-8, tap "Clear Fault Memory", a confirmation dialog box pops up on the screen.

Tap "Yes", the system will automatically delete the currently existing trouble code.

 **Note:** The trouble code will not disappear until the trouble was completely cleared.

5.3.4 Read Data Stream

This option retrieves and displays live data and parameters from the vehicle's ECU.

In Fig. 5-8, tap "Read Data Stream", the system will display data stream items.

Fig. 5-11

On-screen Buttons:

Select Page: Tap it to select all items of the current page. To select certain data stream item, just check the box before the item name.

Unselect: Tap it to deselect all data stream items.

Confirm: Tap it to confirm and jump to the next step.

After selecting the desired items, tap “Confirm” to enter the data stream reading page.

Name	Value	Standard	Unit
A/C Pressure Sensor	772.24	0-1000	Kpa
A/C Pressure Switch	Open (OK)		
Accelerator Pedal Position	21.96	0-100	%
Accelerator Pedal Position Sensor 1	14.43	0-5	V

Fig. 5-12

Notes:

1. If the value of the data stream item is out of the range of the standard (reference) value, the whole line will display in red. If it complies with the reference value, it

displays in black (normal mode).

- The indicator 1/X shown on the bottom of the screen stands for the current page/total page number. Swipe the screen from the right/left to advance/return to the next/previous page.

On-screen Buttons:

Graph: After selecting, tap it to view the waveform. There are 3 types of display modes available for data viewing, allowing you to view various types of parameters in the most suitable way.

- ✓ **Graph** – displays the parameters in waveform graphs. Refer to Fig. 5-16.




Fig. 5-13

- ✓ **Value** – this is the default mode which displays the parameters in texts and shows in list format.
- ✓ **Combine** – this option is mostly used in graph merge status for data comparison. In this case, different items are marked in different colors. See Fig. 5-14.

Free Combine: Tap to select the desired data stream item, and then tap "Confirm" to view the waveform graph of the selected items.




Fig. 5-14

Record: Tap to start recording diagnostic data for future playback and analysis. The saved file follows the naming rule: It begins with vehicle type, and then the record starting time and ends with .x431 (To differentiate between files, please configure the accurate system time). The file is stored in “My Report” under “Profile” menu. For details on playback operations, please refer to Chapter 9.4 “My Report”.

To stop reading the data stream, tap before the recording progress bar.

Save data: Tap to save the current waveform as a diagnostic record.

Report: Tap to access to “My reports”.

6 Reset

The Reset section is specially designed to provide you quick access to the vehicle systems for various scheduled service and maintenance performances. All resetting operations are driven by executive commands. Just by following the on-screen prompts to select appropriate execution options, input correct values or data, and perform necessary actions, the system will guide you through the complete performance.

The most commonly performed service functions contain:

- Oil Reset Service
- Steering Angle Calibration
- Electronic Parking Brake Reset
- Battery Register / Battery Maintenance
- Diesel Particulate Filter (DPF) Regeneration
- Tire Pressure Monitor System Reset

Oil Reset Service

This function can be performed in the following cases:

1. If the service lamp is on, you must provide service for the car. After service, you need to reset the driving mileage or driving time so that the service lamp turns off and the system enables the new service cycle.
2. After changing engine oil or electric appliances that monitor oil life, you need to reset the service lamp.

Steering Angle Calibration

1. To reset the steering angle, first find the relative zero point position for the car to drive in straight line. Taking this position as reference, the ECU can calculate the accurate angle for left and right steering.
2. After replacing the steering angle position sensor, replacing steering mechanical parts (such as steering gearbox, steering column, end tie rod, steering knuckle), performing four-wheel alignment, or recovering car body, you must reset the steering angle.

Electronic Parking Brake Reset

1. If the brake pad wears the brake pad sense line, the brake pad sense line sends a signal sense line to the on-board computer to replace the brake pad. After replacing the brake pad, you must reset the brake pad. Otherwise, the

car alarms.

2. Reset must be performed in the following cases:
 - a) The brake pad and brake pad wear sensor are replaced.
 - b) The brake pad indicator lamp is on.
 - c) The brake pad sensor circuit is short, which is recovered.
 - d) The servo motor is replaced.

Battery Register/Battery Maintenance

This function enables you to perform a resetting operation on the monitoring unit of vehicle battery, in which the original low battery fault information will be cleared and battery matching will be done.

Battery matching must be performed in the following cases:

- a) Main battery is replaced. Battery matching must be performed to clear original low battery information and prevent the related control module from detecting false information. If the related control module detects false information, it will invalidate some electric auxiliary functions, such as automatic start & stop function, sunroof without one-key trigger function, power window without automatic function.
- b) Battery monitoring sensor. Battery matching is performed to re-match the control module and motoring sensor to detect battery power usage more accurately, which can avoid an error message displaying on the instrument panel.

Tire Pressure Monitor System Reset

1. After the tire pressure MIL turns on and maintenance is performed, the tire pressure resetting function must be performed to reset tire pressure and turn off the tire pressure MIL.
2. Tire pressure resetting must be performed after maintenance is performed in the following cases: tire pressure is too low, tire leaks, tire pressure monitoring device is replaced or installed, tire is replaced, tire pressure sensor is damaged, and tire is replaced for the car with tire pressure monitoring function.

Diesel Particulate Filter (DPF) Regeneration

DPF regeneration is used to clear PM (Particulate Matter) from the DPF filter through continuous combustion oxidation mode (such as high temperature heating combustion, fuel additive or catalyst reduce PM ignition combustion) to stabilize the filter performance.

DPF regeneration may be performed in the following cases:

- a) The exhaust back pressure sensor is replaced.
- b) The PM trap is removed or replaced.
- c) The fuel additive nozzle is removed or replaced.
- d) The catalytic oxidizer is removed or replaced.
- e) The DPF regeneration MIL is on and maintenance is performed.
- f) The DPF regeneration control module is replaced.

7 golo

This option aims to help repair shops or technicians launch instant messaging and remote diagnosis, making the repair job getting fixed faster.

Tap “golo” to enter, the screen appears blank by default.

7.1 Interface Layout




Fig. 6-1

1	Search bar	Directly input the username of the CRP MOT to start searching, and then tap the desired one to add it into your friend list.
2	Friend list	By default, it appears blank.
3	Message tab	Once an incoming message reaches, a red dot will appear on the upper right corner of the tab.
4	Contact tab	Tap to enter the friend list.

7.2 Add Friends

In the search bar, input the partner's username and tap “Search” button next to the search bar to start searching from Launch's golo business database.

The partner must be the golo user who has registered their Launch's diagnostic tool. They may be the following:

- Workshop
- Technician
- golo users

Once the result matches the keyword, a screen similar to the following will appear:




Fig. 7-2

Tap "Add", a dialog box pops up:




Fig. 7-3

Tap "Confirm" to send your request.

Once the partner receives the request, a beep will sound. Tap "Message" and then tap "Agree" to confirm and his/her name will appear in the friend list.



7. 3 Start Instant Messaging

Note: The I/M (Instant Messaging) function is open to all users who had Launch's diagnostic tool equipped with this module. But for remote diagnosis, it only can be launched between two diagnostic tools that have the same product configurations.

After adding your friend, tap the desired username directly from the friend list to enter the instant messaging interface.



Fig. 7-4

Tap the input field and use the on-screen keyboard to enter the text message, and then tap “Send” to send it; tap  to send the voice message; tap  to choose to send files, pictures etc.

7. 4 Launch Remote Diagnosis

Note: Before performing this operation, please make sure the following no matter which side sends the remote request:

- Turn on the vehicle power supply.
- Throttle should be in a closed position.
- The VCI connector should be properly connected to the vehicle’s DLC and a successful communication is required.
- The same diagnostic software is installed on both sides.
- The remote diagnosis operation only can be launched between two diagnostic tools that have the same product configurations.

Tap  to display more options:



Fig. 7-5

Tap “Remote Diangostic”, a pull-down menu including the following options appear:




Fig. 7-6

Actions	Results
Send remote diagnostic reservation	Tap it and input the reservation title of the remote diagnosis, and then tap "Confirm" to send.
Invite remote diagnostic assistant	<p>If you need support, just use this option to invite a technician to perform a remote control on your tool.</p> <pre> graph TD A[Tap "Invite remote diagnostic assistant"] --> B[Choose the desired diagnostic software] B --> C[Wait for partner's confirmation] C --> D[Start connecting after request confirmed] D --> E[Start Diagnosis] E --> F[Generate diagnostic report] </pre>
Request control remote device	Request to control the partner's device remotely to help him diagnose the vehicle.

	<pre>graph TD; A[Tap "Request control remote device"] --> B[Wait for partner's confirmation]; B --> C[Start connecting after request confirmed]; C --> D[Start Diagnosis]; D --> E[Generate diagnostic report];</pre>
Cancel	To cancel this operation.

8 Software Update

Once a newer diagnostic software version is detected, a prompt message will pop up on the screen. To keep synchronized with the latest version, tap “Update now” to enter the update center.

Tap “Update” to start downloading. Once downloading is finished, the software packages will be installed automatically.

Note: Before update, please make sure CRP MOT has a strong Wi-Fi connection.

9 Profile

This function allows users to manage the VCI connector and diagnostic reports, and personal information.

9.1 My connector

This option is used to manage all your activated connectors.

If several VCI connectors are activated on this tool, a list of connectors will be displayed on the screen. Once you choose the connector that belongs to other account, you have to log out, and then input the right account to continue.

9.2 Activate connector

If the VCI connector has not been activated during the product registration, or if you have lost the bound connector and bought another brand-new one, please use this option to activate it.




Fig. 9-1

Input the Serial Number and Activation Code, and then tap “Activate” to activate it.

Note: The Serial Number and Activation Code can be found from the password envelope.

9.3 Firmware Fix

Use this item to upgrade and fix diagnostic firmware. During fixing, please do not cut power or switch to other interfaces.

9.4 My report

This option is used to view the diagnostic report generated in process of vehicle diagnosis. Additionally, delete, share operations are also supported.

Tap “**My Report**”, there are total 3 options available.

If user records the running parameters while reading data stream, it will be saved as .x431 file and appear under **Diagnostic Report** tab.

Remote Diagnostic Report lists all records generated in process of remote diagnosis.

In case the DTC result is saved on Read Trouble Code page, the files will be listed under **Diagnostic Report** tab.




Fig. 9-2

9.5 Diagnostic feedback

This item allows you to feedback your diagnostic problems to us for analysis and troubleshooting.

9.6 Profile

Use this item to view and configure personal information.

9.7 Change password

This item allows you to modify your login password.

9.8 Log out

This option allows you to logout the system.

To logout the current user ID, tap “Log out”.

10 Settings

This function allows users to manage your personal information, configure system settings and feedback your vehicle issues or diagnostic reports to us for analysis.

10.1 Units of Measurement

It is designed to set the measurement unit. Metric System and English System are available.

10.2 Print Information

This option lets you define your print information. It mainly includes Workshop, Address, Telephone, Fax and License Plate.

After inputting, tap on "Save" to save it.

10.3 Diagnostic Feedback

This item allows you to feedback your diagnostic problems to us for analysis and troubleshooting.

10.4 About


The software version information and disclaimer are included.

11 Others


11.1 Email

The function allows you to send and receive emails.

11.1.1 Configure an email account

 Note: Before sending or receiving email, you have to set up an email account. In addition, this function requires a stable network connection.

1. On the home screen, tap **Email**.
2. Choose the desired email account type.
3. Input email address and password, tap “Next”.

 Note: If “Manual setup” is selected, please consult your email service provider for detailed parameter setting.

4. Follow the on-screen instructions to proceed until the system prompts you that the account setup has been finished.

11.1.2 Add an email account

1. Tap **Settings** -> **Accounts**.
2. Tap **Add account**.
3. Choose the desired account type.

11.2 Browser

11.2.1 Open browser

On the home screen, tap **Browser** to launch the browser. You can choose the desired homepage or input the website address to browse.




Fig. 11-1

-
- 1 Return to the previous page.
 - 2 Advance to the recently visited page.
-

3	Refresh the current page.
4	Close the current page.
5	Create a new tab.
6	Input a web address.
7	Add the current page as bookmark.
8	Open search bar.
9	Open bookmark list.
10	View more options.

11.2.2 Download files

Files, pictures, and applications can be downloaded from the website in browser.
For example:

Tap and hold a picture, then choose “Save image” from pop-up menu to download it.

To download a link, tap and hold it, and then choose “Save link”.

To protect your CRP MOT and personal data, please download applications from trusted sources. To configure it, tap **Settings** -> **Security**, and then slide the Unknown sources switch to off.

11.3 Synchronization

You can transfer media files and APK between the PC and CRP MOT.

11.3.1 Connect to PC

1. Use the USB cable to connect the CRP MOT to your PC.
2. Swipe from the top, a message “Connected as a media device” appears.

11.3.2 Run on PC

Perform the following steps:

- Locate the new disc.
- Copy the files.

11.3.3 Install an application


Do the following steps:

1. Tap **Settings** -> **Security**, and set the “Unknown sources” to ON, which allows you to install apps from unknown sources.
2. A dialog box appears on the screen, tap “OK” to confirm.
3. Set the tool as “Connected as a media device”, and copy the APK file from

the PC to the tool.

11.4 Clear Cache

Doing so clears all browsing records and accounts and enables CRP MOT to run smoothly and quickly.

1. Tap **Settings** -> **Apps**.
2. Tap  and select "Sort by size" to arrange all applications in size order.
3. Tap certain application, then tap "Clear Cache" to release the space these cache files are occupied.


12 FAQ

1. How to save power?

- Please turn off the screen while CRP MOT keeps idle.
- Set a shorter standby time.
- Decrease the brightness of the screen.
- If WLAN connection is not required, please turn it off.
- Disable GPS function if GPS service is not in use.

2. What should I do in case I forgot the screen lock?

You can set screen lock as pattern or password. If you forgot the password, please consult your device provider or reset your device.

 Warning: Resetting may cause data loss. Before use, please make sure important data has been backed up.

3. How to do if the system runs slow?


In this case, please do the followings:

> Check all running applications and stop the unnecessary applications (Steps: Settings -> Apps -> Running -> Tap the desired application and then tap "Stop").

> Check all installed applications, remove the unnecessary applications (Steps: Settings -> Apps -> Downloaded -> Tap the desired application and then tap "Uninstall").

If all steps mentioned above are finished and the system still works slowly. Please try to close the system and reboot your CRP MOT.

4. How to reset CRP MOT?

 Resetting may cause data loss. Before doing so, please make sure important data and information has been backed up.

Do the following to reset CRP MOT:

1. Tap "Settings" --> "Back & Reset";
2. Tap "Factory data reset";
3. Tap "Reset tablet";
4. Tap "Clear all data" to start resetting until the tool automatically reboots.

Warranty

THIS WARRANTY IS EXPRESSLY LIMITED TO PERSONS WHO PURCHASE LAUNCH PRODUCTS FOR PURPOSES OF RESALE OR USE IN THE ORDINARY COURSE OF THE BUYER'S BUSINESS.

LAUNCH electronic product is warranted against defects in materials and workmanship for one year from date of delivery to the user.

This warranty does not cover any part that has been abused, altered, used for a purpose other than for which it was intended, or used in a manner inconsistent with instructions regarding use. The exclusive remedy for any automotive meter found to be defective is repair or replacement, and LAUNCH shall not be liable for any consequential or incidental damages.

Final determination of defects shall be made by LAUNCH in accordance with procedures established by LAUNCH. No agent, employee, or representative of LAUNCH has any authority to bind LAUNCH to any affirmation, representation, or warranty concerning LAUNCH automotive meters, except as stated herein.

Disclaimer

The above warranty is in lieu of any other warranty, expressed or implied, including any warranty of merchantability or fitness for a particular purpose.

Purchase Order

Replaceable and optional parts can be ordered directly from your LAUNCH authorized tool supplier. Your order should include the following information:

Order quantity

Part number

Part name

Customer Service

Any question during the operation, please call 86-755-84528722.

If your unit requires repair service, return it to the manufacturer with a copy of the sales receipt and a note describing the problem. If the unit is determined to be in warranty, it will be repaired or replaced at no charge. If the unit is determined to be out of warranty, it will be repaired for a nominal service charge plus return freight. Send the unit pre-paid to:

Attn: Customer Service Department

LAUNCH TECH. CO., LTD.

Launch Industrial Park,

North of Wuhe Avenue,

Banxuegang, Bantian,
Longgang, Shenzhen, Guangdong
P.R.China, 518129
Launch website: <http://www.cnlaunch.com>
<http://www.x431.com>
<http://www.dbscar.com>

Statement:

LAUNCH reserves the rights to make any change to product designs and specifications without notice. The actual object may differ a little from the descriptions in the manual in physical appearance, color and configuration. We have tried our best to make the descriptions and illustrations in the manual as accurate as possible, and defects are inevitable, if you have any question, please contact local dealer or after-sale service center of LAUNCH, LAUNCH does not bear any responsibility arising from misunderstandings.